

ADD-A-BATHROOM

Ph: 1300 559 121

info@addabathroom.com.au

www.addabathroom.com.au

Installation guide for Add-A-Bathroom Outdoor Bathrooms.

Please note that this guide is provided for general information purposes only and should not be relied upon without professional advice about your personal situation and installation requirements. As this guide does not take personal circumstances into account and as any installation is beyond the control of Add-A-Bathroom Pty Ltd, no responsibility is accepted nor warranty implied by Add-A-Bathroom Pty Ltd by the publishing or use of this guide.

Add-A-Bathroom Outdoor Bathrooms are assembled in our modern production facility and are delivered complete and ready for connection and installation.

No specialised tools are required to install an Add-A-Bathroom Outdoor Bathroom. A forklift, truck crane or similar will be required to locate the bathroom in position. All electrical and plumbing connections must be performed by appropriately licensed contractors.

If in strong wind areas and for other site-specific installation requirements, please consult your local building consultant.

- Install 4 concrete reinforced pads in accordance with AS2870 or other relevant Australian Standards, minimum size 300 x 300 x 600mm deep, positioned one at each corner of the Outdoor Bathroom.
- Ensure sewer pipework, hot and cold plumbing and electrical connections are correctly placed to receive your Outdoor Bathroom, and that the area is vacant and prepared as necessary.
- Manoeuvre the bathroom into its final position. Ensure the bathroom is level and stable.
- Connect the sewer pipework first, as some minor adjustment to position may be required.
- Connect the hot and cold plumbing to the factory fitted connection points. If your Outdoor Bathroom has been supplied with an optional Hot Water Service, only cold water plumbing connection will be required.
- Secure the bathroom to the concrete pads by using a minimum 4 (1 in each corner) Dynabolts ^(TM) of a minimum size 150 x 20mm (fitted in accordance with manufacturer's specifications).
- Connect electrical supply, and gas if required.
- That's it, sit back and enjoy your new Add-A-Bathroom Outdoor Bathroom!